




TVC00046200061




TVC00046300061




TVC00045600061



TVC00045700061




TVC00045800061






TVC00045900061

WALL BRACKETS WALL ELBOWS WALL HAND SHOWER HOLDER



- (D) Montageanleitung**
- (GB) Installation instructions**
- (FR) Instructions de montage**
- (CN) 安装说明书**
- (ES) Instrucciones de instalación**




TVC00046200061




TVC00045600061






TVC00045800061



TVC00045900061



Controlled

Änderungen vorbehalten
We reserve the right to make alterations
Sous réserve de modifications
我们保留作出改变的权利
Nos reservamos el derecho de hacer
cambios o modificaciones


Villeroy & Boch
1748

Villeroy & Boch AG
Postfach 12 30 - 66689 Mettlach
Germany
Tel: +49 (0) 6864 816000
Fax: +49 (0) 6864 815687
www.villeroy-boch.com

Villeroy & Boch Service centre
Tel: 400-820-1748

TVM00001001000-V28-2015