
Assembly Instructions

1.Component List

Identify all components are present prior to installation.



1. Square cover	x1
2. Flange	x1
3. Silicone Washer	x1
4. Rubber Washer	x2
5. Overflow ring	x1
6. Backnut	x1
7. O-ring	x2
8. Flexible tube	x1
9. Overflow elbow	x1
10. Rubber washer	x1
11. Overflow washer	x1
12. Square overflow cover	x1

2. Installation steps




Figure 1




Figure 2

①. Pass the flange(2) through the washer(3), the drain hole of the bathtub, the washer(4), the overflow ring(5) and the washer(4) in sequence. Finally locked with a backnut(6),and then put the square cover(1) in the flange(2). (As Figure 1 showed)

②. Pass the screw of the square overflow cover(12) through the overflow washer(11), the overflow hole of the bathtub and the rubber washer(10). Then lock it with the overflow elbow(9). (As Figure 2 showed)

③. Insert the flexible tube(8) into the installed overflow ring(5) and overflow elbow(9) to complete the installation.(As Figure 3 showed)

④. Check all joints and connections for leaks.





Figure 3


3. Installation complete drawing



5.21028-00 INFINITY Слив-перелив Square, Click-Clack, латунь/пластик, L=550мм, хром (265556)

5.21028-31 INFINITY Слив-перелив Square, Click-Clack, латунь/пластик, L=550мм, черн.мат (265557)

INFINITY



ВНИМАНИЕ! Для ванн с толщиной борта 2-8мм.